



## RV WINTERIZATION KIT STEP BY STEP GUIDE

PART NO. 90145



### **IMPORTANT:**

It is essential that you and any other operator of this product read and understand the contents of this guide before installing and using this product.

**SAVE THIS GUIDE FOR FUTURE REFERENCE**

**USER MANUAL**

## RV WINTERIZATION KIT

### Pressure Regulator Installation instructions:

---

1. Connect the quick connect coupler from winterization kit to the outlet side of the pressure regulator (see below fig.1)
2. Connect the quick connect stud fitting from winterization kit to inlet side of the pressure regulator (see below fig.1)



fig. 1



fig. 2

## RV WINTERIZATION KIT

### Using RV Winterization Kit w/VIAIR 400P/450P-RVS Air Compressor Instructions

---

1. Connect the primary air hose to your VIAIR compressor
2. Connect the tire inflation gun to the primary air hose
3. Connect the quick connect stud from the Winterization Kit to the quick connect coupler on the Tire Inflation Gun. (see fig. 2)
4. Connect the compressor to the battery – either the RV engine battery, battery connected to shore power, or any other vehicle.
5. Turn the compressor ON makes sure the engine is running.
6. Adjusting the pressure regulator: pull the trigger on the tire inflation gun, while holding on the trigger pull out the knob on the winterization kit regulator, turn the knob to adjust the pressure to no more than 30 psi, push the knob back in place when pressure reached 30 psi or less on the regulator's gauge, release the trigger.
7. Disconnect RV from outside water source
8. Turn off all RV power and shut off propane
9. Bypass your RV water heater
10. Open all faucets in the RV
11. Open the system drain valves in the RV letting the water empty
12. Flush the toilet in the RV to clear any water
13. Connect the blow out plug from the winterization kit to the city water inlet...not the fresh water tank
14. Connect the blow out plug to the female quick connect coupler on the regulator.
15. To start: press trigger and allow compressor to run until all water is blown out from all faucets and drain valves
16. To stop: release the trigger and disconnect the blow out plug from the water inlet. Turn the compressor off and disconnect the power cable from the battery.

## STEP BY STEP GUIDE

**LIMITED WARRANTY:**

VIAIR Corporation warrants this product, when properly installed and under normal conditions of use, to be free from defects in workmanship and materials for a period of one year from its original date of purchase. To receive warranty service or repair, please contact VIAIR Corporation.

Returns should be made within one year of the date of purchase, after a Return Goods Authorization (RGA) number has been assigned by VIAIR Corporation. To obtain RGA, fax a copy of your receipt to (949) 585-0188. For complete warranty details, please visit: [www.viaircorp.com/warranty](http://www.viaircorp.com/warranty)

**PLEASE NOTE:**

THIS WARRANTY COVERS PRODUCT DEFECTS ONLY; IT DOES NOT COVER INCIDENTAL OR CONSEQUENTIAL DAMAGES AS RESULT OF MISUSE OR ABUSE.

This Manual is proprietary to VIAIR Corporation and no ownership rights are hereby transferred. No part of the Manual shall be used, reproduced, translated, converted, adapted, stored in a retrieval system, communicated or transmitted by any means, for any commercial purpose, including without limitation, sale, resale, license, rental or lease, without the prior express written consent of VIAIR.

VIAIR does not make any representations, warranties or guarantees, express or implied, as to the accuracy or completeness of the Manual. Users must be aware that updates and amendments will be made from time to time to the Manual. It is the user's responsibility to determine whether there have been any such updates or amendments. Neither VIAIR nor any of its directors, officers, employees or agents shall be liable in contract, tort or in any other manner whatsoever to any person for any loss, damage, injury, liability, cost or expense of any nature, including without limitation incidental, special, direct or consequential damages arising out of or in connection with the use of the Manual.



15 EDELMAN • IRVINE, CA 92618  
TEL: (949) 585-0011 • FAX: (949) 585-0188  
[www.viaircorp.com](http://www.viaircorp.com)